




MANUAL


XG205x **POWER BANK 5.000**

Gebruiksaanwijzing
Gebrauchsanweisung
Mode d'emploi
Bruksanvisning
Brugsvejledning


Käyttöopas
Uživatelská příručka
Používateľská príručka
Εγχειρίδιο χρήσης
دەستەبەندی بەکارهێنەر




1 SPECIFICATIONS


 5.000mAh Li-poly / 18.5Wh

 1x USB-C 12W
1x USB-A 12W

 USB-C 12W input

 93.5x63x15.5 mm

 135 grams


 1x USB-A to USB-C cable
1x Manual

When using multiple outputs

When using 2 outputs

1/2 Share 12W

PRODUCT OVERVIEW 2



Output
USB-C 12W **1**


Output
USB-A 12W **2**

Input
USB-C 12W **3**

Power Button **4**

Led Power Indicator **5**

3 CHARGING YOUR DEVICE




COMPATIBLE DEVICES




- 3A** Connect the USB-C end of the charging cable to the USB-C output of the Power Bank and the other end to the input of your device. The charging will start automatically.
- 3B** Charging some devices requires a charging cable other than the one supplied. E.g. an Apple Lightning® or a Micro USB cable.

RECHARGING THE POWER BANK 4




- 4A** Connect the USB-C end of the charging cable to output 1 of the Power Bank and the USB end to a wall charger.
- 4B** For the fastest charging possible use a 12W USB-C charger. This will fully recharge the Power Bank within 2.5 hours.

5 LED POWER INDICATOR



- 5A** Press the Power Button once to display the battery level remaining in the Power Bank via the LED display.
- 5B** Each lit LED light indicates 25% remaining energy in the Power Bank. At 4 lit lights, the Power Bank is fully charged.

IN THE BOX 6



XG205x Power Bank	1
USB-A to USB-C Cable	2
Manual	3

EN - ENGLISH

1 SPECIFICATIONS

2 PRODUCT OVERVIEW

3 CHARGING YOUR DEVICE

3.A Connect the USB-C end of the charging cable to the USB-C output of the Power Bank and the other end to the input of your device. The charging will start automatically.

3.B Charging some devices requires a charging cable other than the one supplied. E.g. an Apple Lightning® or a Micro USB cable.

4 RECHARGING THE POWER BANK

4.A Connect the USB-C end of the charging cable to output 1 of the Power Bank and the USB-C end to a wall charger.

4.B For the fastest charging possible use a 12W USB-C charger. This will fully recharge the Power Bank within 2.5 hours.

5 LED POWER INDICATOR

5.A Press the Power Button once to display the battery level remaining in the Power Bank via the LED display.

5.B Each lit LED light indicates 25% remaining energy in the Power Bank. At 4 lit lights, the Power Bank is as good as fully charged.

6 IN THE BOX

NL - NEDERLANDS

1 SPECIFICATIES

2 PRODUCT OVERZICHT

3 OPLADEN VAN JOUW APPARAAT

3.A Sluit het USB-C uiteinde van de oplaadkabel aan op de USB-C uitgang van de Power Bank en het andere uiteinde op de ingang van je apparaat. Het opladen begint automatisch.

3.B Voor het opladen van sommige apparaten is een andere oplaadkabel nodig dan de bijgeleverde USB naar USB-C kabel. Bijv. een Apple Lightning® of Micro USB kabel.

4 OPLADEN VAN DE POWER BANK

4.A Sluit het USB-C uiteinde van de oplaadkabel aan op uitgang 1 van de Power Bank en het USB-C uiteinde op een wandoplader.

4.B Gebruik een 12W USB-C oplader voor het snelst mogelijke opladen. Hierdoor is de Powerbank binnen 2.5 uur weer volledig opgeladen.

5 LED-STROOMINDICATOR

5.A Druk eenmaal op de aan/uit-knop om het resterende batterijniveau in de powerbank via het LED-scherm weer te geven.

5.B Elk brandend LED-lampje geeft 25% resterende energie in de Power Bank aan. Bij 4 brandende lampjes is de Power Bank zo goed als volledig opgeladen.

6 IN DE DOOS



HIGHER QUALITY
= LOWER IMPACT

CUSTOMER SUPPORT

support@tag.nl
+31 (0)30 635 4800

TELCO ACCESSORIES GROUP

Hoofdveste 19, 3992DH Houten
The Netherlands

#MOREENERGY

XTORM.EU